HARLEY-DAVIDSON® TOURING SINGLE BOLT BAFFLE INSTALLATION INSTRUCTIONS





Thank you for purchasing **RUSH**. We strive for excellence and take pride in making the best exhaust for your Harley-Davidson[®]. We take our full systems to an all new level in the exhaust industry! Our full systems come standard with ceramic coating on both the inside and outside of the head pipe, providing superior heat reduction and quality looks for years to come.

BAFFLE REMOVAL

READ ALL INSTRUCTIONS BEFORE BEGINNING

- Remove baffle mounting hardware located on the bottom side of the muffler. NOTE: Baffles with high mileage may require the use of penetrating oil. If penetrating oil is needed Spray around the rear mounting cup of the baffle. Read instructions on label of penetrating oil to allow product to sit long enough to penetrate through any carbon build up.
- 2. In a well ventilated area, start the bike and allow exhaust to warm up, 5-10 minutes is good. Turn off bike.
- 3. Wearing leather gloves, use Vise Grips or Channel Locks to grip onto the extraction bar of the baffle and begin to pull.
- 4. As you pull on the baffle, begin to twist. Twisting can be clockwise or counterclockwise. Be sure to continue twisting in the same direction and spiral as you pull the baffle out. (Do not twist side to side. This can cause the matting to get bound up between the baffle mounting cups and the muffler body.)

BEFORE INSTALLATION PLEASE READ ALL INSTRUCTIONS

- 1. Slide baffle into muffler shell, being careful to align the slot in the baffle with the bolt hole in the muffler shell.
- 2. Lightly tap baffle to "seat" the baffle in place. This will hold the front of the baffle in place.
- 3. Re-Install baffle mounting hardware. Be sure to apply Blue Loc-Tite on the threads of the mounting hardware before installing.
- 4. RIDE